

**Depth 12mm**



**Led Groove-Panel #28,29,30,31  
on open cabinet bottom panel groove  
start from 32mm of back of the cabinet**